

BIG BOSS BELOW IS SHOWN WITH LID OPEN

- WHEN USING WITH A CONTROLLER YOU WILL NEED TO DISCONNECT THE LARGE RED AND BLACK WIRES FROM 24VAC AND COM ON THE SWITCH BOARD AND WIRE NUT THEM SEPARATELY LIKE SHOWN.

- THE CONTROLLER'S TRANSFORMER WILL PROVIDE THE 24VAC AND COM SIGNALS TO THE SWITCH BOARD.

